


HOPPER INFORMATION SERIES

08 / FIDUCIAL MARKERS

AprilTags with Hopper

Visual IDs for detection, centering and 2D heading alignment.

tag36h11




tag36h11 ID 0

ID + orientation





A visual ID designed for robots



HOPPER FAMILY



- tag36h11
- IDs 0 through 586
- Black and white only
- Up to 3 payload-bit errors accepted

WHY FIDUCIALS

- Known geometry.
- Unique machine-readable ID.
- Orientation from one image.
- No battery or radio on the tag.




How Hopper Studio detects a tag





Coordinates and pose in Hopper Studio



APRILTAG RESULT


- id + family + hamming
- four corners + center in pixels
- bounding box
- centerX / centerY: -100..100
- yaw: normalized around +/-180 deg

DO NOT OVERCLAIM

- Yaw is 2D image-plane orientation.
- It is not full 3D pose or aircraft heading.
- No distance or altitude is returned.
- centerOnAprilTag never lands.



Print cleanly and place deliberately



tag36h11 ID 7

PRINT IN HOPPER STUDIO

- Vision Testing -> AprilTag Detection.
- Choose an ID from 0-586.
- Generate PDF for a full-page US Letter vector tag.
- Print at 100% scale with a clean white margin.

PLACE FOR THE CAMERA

- Keep the sheet flat and well lit.
- Avoid glare, folds, shadows and clipped margins.
- Start large and close; test before increasing height.
- Keep paper and people clear of propellers.



Three block patterns support tag missions

scan for april tags

Fresh scan. Replaces the latest tag list and updates the overlay.

camera sees april tag with ID any / 0-586

Fresh scan. Boolean true when the requested ID is present.

center on april tag [ID] at [power]% | center slack | angle slack | lost searches

1 Scan

Choose requested or nearest tag.

2 Translate

Correct larger x/y error.

3 Stabilize

Reset and wait.

4 Align

Timed yaw correction.

5 Finish

True when centered + aligned.

Defaults: 10% power | +/-5% center | +/-5 deg angle | 3 lost scans | 30 s hard timeout



AprilTags become visual landmarks

CENTERING PAD

Center the camera over one ID, then explicitly land.

ZONE ID

Use different IDs for room regions or task stations.

HEADING CUE

Align the drone's forward axis with the tag x-axis.

SEARCH

Lawnmower scan until any tag or one requested ID appears.

SEQUENCE

Visit IDs in a planned order with a timeout at each.

VERIFY

Require repeated ID/pose agreement before motion.

A tag is a relative visual landmark - not GPS, altitude or collision avoidance.



Reliable tags need reliable experiments

BEFORE FLIGHT

- Confirm the family is tag36h11.
- Test the intended ID, size, angle and lighting.
- Keep the full border and quiet zone in frame.
- Use a lost-tag limit and an overall timeout.
- Plan a safe fallback land.

SOURCES AND FURTHER READING

University of Michigan APRIL Lab - AprilTag

<https://april.eecs.umich.edu/software/apriltag>

AprilTag 2 paper

<https://april.eecs.umich.edu/media/pdfs/wang2016iros.pdf>

Hopper Studio detector and printable tag generator

[lib/apriltags.ts](#), [lib/vision.ts](#) and [README.md](#)

DETECT -> CENTER -> ALIGN -> DECIDE

The mission still owns height, obstacle clearance and landing.